

WSBUD3 Install Instructions

Tools Needed

- 13mm wrench
- 14mm wrench
- Philips screw driver

1. Insert rubber buffers into windscreen with the indent on the front of the windscreen.
2. Place the plastic washers into the buffers.
3. Insert the four screws into the buffers as shown below.



4. Place the provided 10mm nuts into the pre-cut seating on the clamps.
5. Lightly install clamps pointed toward the outside of the windscreen as shown below.



- Next, slide the L- Shaped bracket into the clamps from the bottom. **Do not tighten; you will need to make adjustments later.**



- With your 14mm wrench, loosen the mirrors and remove. Keep in mind, **the right mirror is reverse thread.**
- Remove the nut from the provided bolt and insert into the following hardware as shown below. Lightly tighten by hand.



9. Slide the mounting posts into the clamps as shown below.
10. Adjust the windscreen to your liking and tighten. You may have to loosen the primary mounting bolt to make adjustments to the mirror bracket.



11. Using the 4 washers (two per mirror) and two nuts supplied with the windscreen. Install the mirrors into the bracket and tighten with the 14mm and 13mm wrenches as shown below.



12. Double check that all hardware is secure.